

ENGR 3421: ROBOTICS I

Encoder





Dr. Lin Zhang

Department of Physics and Astronomy
University of Central Arkansas


September 28, 2021




Types of Encoder



Hall Effect



Absolute Encoder vs. Incremental Encoder




Incremental	Absolute
Simpler	More complicated
Output velocity and displacement (optionally direction)	Output position and velocity
Floating origin	Fixed origin
Lower cost	More expensive



Quadrature Encoder

A Leads B for Counter Clockwise



A	0	0	1	1
B	0	1	1	0
#	1	4	3	2

Clockwise

A	0	1	1	0
B	0	0	1	1
#	1	2	3	4

Counter Clockwise



Encoder Usage

Details for item #4805

Exact gear ratio: $\frac{22 \times 22 \times 22 \times 22 \times 24}{12 \times 10 \times 10 \times 10 \times 10} \approx 46.85:1$

Using the encoder

A two-channel Hall effect encoder is used to sense the rotation of a magnetic disk on a rear protrusion of the motor shaft. The quadrature encoder provides a resolution of 48 counts per revolution of the motor shaft when counting both edges of both channels. To compute the counts per revolution of the gearbox output, multiply the gear ratio by 48. The motor/encoder has six color-coded, 8" (20 cm) leads terminated by a 1×6 female header with a 0.1" pitch, as shown in the main product picture. This header works with standard [0.1" male headers](#) and our male [jumper](#) and [precrimped wires](#). If this header is not convenient for your application, you can pull the crimped wires out of the header or cut the header off. The following table describes the wire functions:

$$\omega = \frac{c}{CPR \cdot t} \cdot 2\pi$$

ω : shaft angular speed, c : counts, CPR : counts per revolution, t : time

$$\dot{\theta} = \omega / i$$

$\dot{\theta}$: wheel angular speed, i : gear ratio

$$v = R \cdot \dot{\theta}$$

v : vehicle speed, R : wheel radius

